


MAINTENANCE

Wipe off dust with a dry, soft cloth. Remove greasy spots etc. with a soft, damp cloth with a mild detergent. Never use detergents containing abrasives and solvents.

TECHNICAL DATA

Supply Voltage: 220-230V / 50-60Hz
Rating: E27 Lamp Holder
Max: 1 x 40W



READ BEFORE USE

USER GUIDE

LAMP, OPAL
203970116



house doctor

HOUSE DOCTOR GROUP APS
Industrivej 29 · 7430 Ikast · Denmark
Denmark@housedoctor.com
www.housedoctor.com



house doctor

ASSEMBLY

WARNING

Always call a professional/qualified electrician for installation of the lamp.
Switch off the main electric supply before starting installation/wiring of the lamp.

